

K

Webbing

Hem 20 mm

Fold

With: 250 mm

Webbing

E

NOTE! Do not fold and make the hem before part 1, 2, 3 and 7 are assembled.

Part 9, Shoulder Strap

Part 9, Shoulder Strap

Webbing









+10 mm
seam allowance

+10 mm
seam allowance

7

Height:
410 mm





Part 6, Shoulder Strap, Lower Fastening

Part 6, Shoulder Strap, Lower Fastening

Backpack BC18 Back, Ver 1.0

Scale 1:1

All measurements in mm

Copyright © Anders Jonsson 2018

www.andersj.se



Webbing

+10 mm seam allowance

Webbing

